

“VK 100”

- STEAM CLEANER -

The most compact table steam cleaner of the “IV Line”. This device respects the tradition of sturdiness, practicalness and long lasting life of our products.

Connection to the water mains is not required. Quick and easy to install: just pour decalcified water into the tank and plug it in; the appliance will be ready in approximately 10 minutes, then all you will have to do is to top up the water tank whenever indicated by the yellow pilot light.

Decalcified water tank

- Manually-filled water tank whereby the device can be moved around.
- Easy filling: 65mm Ø inlet hole.
- The tank can be topped up without having to switch off the appliance.

Gun

STEAM OUTLET

- Practical and with excellent thermal insulation.
- Ergonomic, easy to use.
- « Sensor » control lever.
- Safety button.

Pilot light

- Green light:
it indicates ignition.
- Red light:
it indicates the lack of water in the tank.
- Blue light:
it indicates the functioning of the water pump.
- Yellow light:
it indicates the functioning of the heating resistance.

